

▼ MORE TRANSACTIONS

Gift Card - Activate

Gift Card - Redeem

Gift Card - Reload

Gift Card - Balance Inquiry

Gift Card - Balance Transfer

Gift Card - Cash Out

Gift Card - Close

Partial Approval

Refund

Sale Swipe

Sale Manual

Settlement

Balance Inquiry

TeleCheck® Sale

Tip Adjustment

Void

More Transactions



Refund Transaction

Use this procedure to issue a refund for returned merchandise or service reimbursement. Do not issue a refund to correct a duplicate transaction. Do not issue a refund on a transaction that is in the current, open batch. A Void must be performed.

Press the blue button above **CREDIT**.

Transaction Steps

Store & Forward Steps

Programming Steps

Reporting Steps

Installation Steps